



360 SERIES



2022 EDITION

**ASSEMBLY
MANUAL**

360 SERIES ASSEMBLY MANUAL

INTRODUCTION

Follow this guide to assemble a series 360 Hunting Blind from start to finish.

If you purchased a tower stand with your blind, please refer to that assembly guide to assemble the tower first, then come back to finish the setup of the blind on the fully assembled tower stand.



SUPPLIES NEEDED

- T-50 construction stapler
- Utility knife
- Impact Driver
- Caulk gun
- Level
- Flat bar or prybar
- 4 - 8" - 12" Pressure Treated 4 X 4s

PARTS LIST

360 STANDARD

- 1 floor
- 1 floor carpet
- 12 wall panels
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

360 PRO

- 1 floor
- 1 floor carpet
- 8 wall panels with standard windows
- 4 wall panels with archery windows
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

360 PRO XL

- 1 floor
- 1 floor carpet
- 8 wall panels with standard windows
- 6 wall panels with archery windows
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

SAFETY DISCLAIMER

At no time shall 360 Hunting Blinds be liable for any accidents due to normal or improper use of blinds or tower stands.

We recommend that you follow standard safety procedures when entering and exiting the blind, or climbing or descending the ladder.

Always use a gear rope to raise and lower your equipment into the blind.

Always use the handrail with both hands when climbing the ladder.

Never use the door handle to pull yourself onto the platform or stabilize your entry and exit.

STEP 1

INSTALL THE TOWER STAND

If you purchased a tower stand, please refer to tower stand instruction manuals before moving to step 2.

STEP 2

INSTALL THE CARPET

Align the carpet roll to the edges of the blind floor and begin fastening with a hand held Stapler. Work from one end of the floor to the other, working out the wrinkles and continually aligning the edges as you go. Use a utility knife to trim carpet that extends past the edge of the floor.



STEP 3

INSTALL THE FIRST PANEL

Set the first panel into place. Have one person hold the top of the panel while another person aligns the bottom.

Make sure the corners of the wall panel match with the corner of the floor.

Use a 3" screw to secure the panel to the floor.



STEP 4

CAULK PANEL EDGE

Run a bead of caulk along the leading edge of the first panel right on the seam of the frame and the exterior siding.



STEP 5

ADD WALL PANELS

Always check to make sure the panels are flush at the top and outside. Fasten the panels together with a 3" screw starting at the top, and bottom, then two more screws in between.

ATTENTION: Wait to screw the wall panels to the floor until all the panels and roof are assembled.



STEP 6

REPEAT

Repeat steps 4 and 5 for the remaining wall panels except the door panel, which will be installed after the roof is lifted into place.

Tip: leaving an extra wall panel off will make it easier to set the roof in place.



STEP 7

LIFT THE ROOF

Lift the roof to the top of the blind and rest it on top of the wall panels.

Balance it toward the back of the blind far enough to leave room to install the remaining panels.



STEP 8

INSTALL THE LAST PANEL

With the roof resting on top of the wall panels, go ahead and install the remaining panels.



STEP 9

INSTALL THE DOOR PANEL

If you fastened any wall panels to the floor, remove those screws so you can shift the wall panels as needed.



STEP 10

FASTEN THE ROOF

Center the roof on the blind.

Screw through the top of the wall panels into the roof panel with **SHORT** screws.

Work your way around the blind, pushing or pulling on the wall panels to align them with the roof as closely as possible.



STEP 11

FASTEN THE WALLS

Fasten the wall panels to the floor with at least one 3" screw per panel.



STEP 12

TOUCH UP

Use the touch up paint provided in the kit to touch up any nicks or scratches that can occur during setup.